

Material:	Kanäle	Kanal	Funktion	Kanal				Startkanäle	Adresse		
GLP X4S	18	1	PAN	1				BACK / BÜHNE / STAGE:			
Modus Normal		2	Pan Fine	2				X4 1	20	Hi Ob Li	
<u>18 Kanäle</u>		3	Tilt	3				X4 2	40		
<u>"X4"</u>		4	Tilt Fine	4				X4 3	60		
		5	Color fixed	5				X4 4	80	Hi Ob Re	
		6	ROT	6				X4 5	100	Hi Un Li	
		7	GRÜN	7				X4 6	120		
		8	BLAU	8				X4 7	140		
		9	WEISS	9				X4 8	160	Hi Unt Re	
		10	Shutter	10				X4 9	180	Front Li	
		11	Dimmer	11				X4 10	200	Front Re	
		12	CTO Color Correction	12				FRONT:			
		13	Control / Reset	13	250	bis	255	Reset	X4 11	220	FOH <<
		14	Pan / Tilt Makros	14					X4 12	240	FOH <
		15	Speed	15					X4 13	260	FOH >
		16	ZOOM	16					X4 14	280	FOH >>
		17	Pattern	17							
		18	Pattern 2	18							
Pinspot	6	1	Rot	1				Pin 1	300	Li Oben	
Modus 6 Kanal		2	Grün	2				Pin 2	310		
<u>"Pin"</u>		3	Blau	3				Pin 3	320		
		4	Weiss	4				Pin 4	330		
		5	Dimmer	5				Pin 5	340		
		6	Makro	6	0	ohne Funktion		Pin 6	350		
					01-010	Musiksteuerung		Pin 7	360		
					011-255	Strobe zunehmend		Pin 8	370	Re Oben	
								Pin 9	380	Li Unten	
								Pin 10	390		
								Pin 11	400		
								Pin 12	410		
								Pin 13	420		
								Pin 14	430		
								Pin 15	440		
								Pin 16	450	Re Unten	
COB Blinder	2	1	Li Seite					COB BI 1	460		
2 Kanal Mode		2	Re Seite						461		
<u>"COB BI"</u>								COB BI 2	462		
									463		
								COB BI 3	464		
									465		
								COB BI 4	466		
									467		
Nebel	2	1	Nebel					Nebel	500		
Windmaschine		2	Wind					Fan	501		